
# **belifires** <sup>gas fires</sup>

# **Preparation manual**

Box Gas 45 MF



Serial number: Production date:

#### © Barbas Bellfires BV

This document or parts thereof may not be reproduced, stored in a retrieval system, or transmitted, in any form or by any means, electronic, mechanical, photocopying, recording, nor otherwise, without the prior written permission of Barbas Bellfires BV. This document could contain technical inaccuracies or typographical errors. Barbas Bellfires BV reserves the right to revise this document from time to time in the contents thereof.

#### **Contact information**

Barbas Bellfires BV Hallenstraat 17, 5531 AB Bladel, The Netherlands E-mail: info@bellfires.com www.barbasbellfires.com

# Contents

1	Ab	out this document	4
	1.1	How to work with this document	
	1.2	Warnings and cautions used in this document	
	1.3	Related documentation	4
2	Ov	erview of the concentric flue system	5
3	Sat	fety	6
	3.1	Safety instructions for installation	
4	Re	quirements	7
	4.1	Requirements on the location	
	4.2	Other requirements	
	4.3	Requirements on the roof and wall outlet	
	4.4	Requirements on the concentric flue system	
		<ul><li>4.4.1 Possibilities for a concentric flue system with a roof outlet</li><li>4.4.2 Possibilities for a concentric flue system with a wall outlet</li></ul>	
5	Το	chnical specification	17
0	5.1	Dimensions Box Gas 45	
	5.2	Dimensions Box Gas 45 with Storage module	
	5.3	Dimensions of the restriction plate	
6	Ava	ailable components for the concentric flue system	20
-	6.1	Appliance part list	
	6.2	Bellfires - Muelink & Grol system Ø100 - Ø150	
	6.3	Poujoulat - DUOGAS system Ø100 - Ø150	27
	6.4	Ontop - Metaloterm US system Ø100 - Ø150	
	6.5	Jeremias/STB - H-Twin system Ø100 - Ø150	
	6.6	Jeremias - TWIN-GAS system Ø100 - Ø150	
	6.7	Modinox - PLA system Ø100 - Ø153	

# 1 About this document

This document shows the necessary information to do these tasks on the Box Gas 45 MF:

• Preparation for installation

This document refers to the Box Gas 45 MF as 'the appliance'. This document is an essential part of your appliance.Read it carefully before you do work on the appliance. Keep it in a safe place.

The original instructions of the document are in English. All other language versions of the document are translations of the original instructions. It is not always possible to provide a detailed illustration of every single item of the equipment. The illustrations in this document show a typical setup. The illustrations are for instructional use only.

#### 1.1 How to work with this document

- 1. Make yourself familiar with the structure and content of the document.
- 2. Read the safety section in detail.
- 3. Make sure that you understand all the instructions.
- 4. Do the procedures completely and in the given sequence.

#### 1.2 Warnings and cautions used in this document

#### Warning

If you do not obey these instructions, there is a risk that can cause personal injury or death.

#### Caution

If you do not obey these instructions, there is a risk of damage to the equipment or to property.

#### Note

A note shows more information.

Symbol	Description
	Visual sign that there is a hazard
i	Visual sign that there is a notice

#### 1.3 Related documentation

- Preparation manual
- Installation and maintenance manual
- User manual
- Assembly instructions for concentric flue system

# 2 Overview of the concentric flue system

The concentric flue system provides the appliance with combustion air and removes the flue gases from the appliance. The concentric flue system is made of these items:

Item	Description	
Concentric flue	The concentric flue is a pipe with an inner pipe. The inner pipe is used as flue gas channel and the space between the inner pipe and the outer pipe is used as combustion air channel	
Flue gas channel	The flue gases from the appliance flow through the channel to the outlet by a natural draft	
Combustion air channel	Supplies the appliance with fresh air from the outlet through the channel	
Outlet/terminal	Entry for the combustion air channel and exit for the flue gas channel	

# 3 Safety

3.1

Safety



Caution:

Safety instructions for installation

- The appliance must be installed as a 'room sealed system' appliance by a certified and registered gas installation engineer in accordance with the supplied installation instructions, and nationally and locally applicable regulations.
  - If you have any questions regarding the installation, consult your local gas company.
- Only use items in the installation that are specified in this manual and the related documents.
- Only use the following brands for the installation of the concentric flue system:

Manufacturer	system
Bellfires	Muelink & Grol system
Poujoulat	DUOGAS system
Ontop	Metaloterm US system
Jeremias/STB (STB = Schoorsteen TechniekBrummen NL)	H-Twin system
Jeremias	TWIN-GAS system
Modinox	PLA system

- Do not use a combination of parts from different brands for the installation of the concentric flue system.
- Before beginning the installation, check that the details on the rating plate correspond to the gas type and supply pressure to which the appliance will be connected.

# 4 Requirements


#### 4.1 Requirements on the location

- The floor must be sufficientlystrong and stable, because of the weight of the appliance.
- Make sure that you keep the minimum safety distances of the appliance to flammable and nonflammable materials. Refer to the installation and maintenance manual.
- Situate the appliance in such a way that the concentric flue outlet connection isprecisely in line with the concentric flue pipe to the ceiling or wall.
- If the fire burns in the appliance, make sure that the wall temperatures, and floor temperatures below and in front of the appliance, cannot be higher than 85 °C.
- Make sure that the room where the appliance is installed is properly ventilated.

#### 4.2 Other requirements

- The gas supply connection is located at the rear of the appliance for an easy connection to all directions.
- Only use gas piping of at least 1/2" and a shut-off valve to connect the gas supply to the gas connection of the appliance.
- Make sure that there is a wall socket with earth connection nearby the appliance. The socket must be accessible at all times. The powercable (+ 0.5 m) is coming from the rear of the appliance.
- If the wall of floor is made of flammable material, take correct safety measures. Refer to the installation and maintenance manual.
- If the concentric flue system is installed in a chimney that is used for wood or coal fire, clean the chimney.

#### 4.3 Requirements on the roof and wall outlet



Refer to the table hereunder for explanation of the figure.



**Note:** All the minimum distances in the table are guidelines. Consult your national and local regulations for the exact minimum distances.

Minimum separation distances for roof and wall outlet(terminal) in mm					
Location					
Α	A Below an opening <sup>1</sup> on the same wall/roof				
В	Above an opening <sup>3</sup> on the same wall/roof	700			
С	Horizontally to an opening <sup>3</sup> on the same wall/roof	700			
D	Horizontally to a facing opening <sup>3</sup> in a opposite wall	2000			
E	From a roof terminal under an opening <sup>3</sup> in a nearby rising wall	4000			
F	Above a flat or pitched roof	300			
G	Horizontally from a terminal on the same roof	300			
Н	From a structure (e.g. brick chimney) on the roof	300			
I	Below a roof window in a pitched roof	2000			
J	J Above a roof window in a pitched roof				
K	K Horizontally to a roof window in a pitched roof				
L					
М	From a vertical drainpipe or soil pipe	300			
	Below gutters, soil pipes or drainpipes, made of flammable materials	500			
N	Below gutters, soil pipes or drainpipes, made of non-flammable materials	300			
	Below eaves, made of flammable material	500			
0	Below eaves, made of non-flammable material	300			
Р	Below balcony <sup>2</sup> or car port roof	2000			
Q	Beyond the balcony <sup>4</sup> edge	0			
R	On either side of a balcony <sup>4</sup>	1500			
S	Above ground, roof or balcony <sup>4</sup> level	300			
Т	From a surface facing the terminal	500			
U	U From a terminal facing the terminal (at the same height)				
V	V From an opening in the car port into the building				
W	W Vertically from a terminal on the same wall				
Х	X Horizontally from a terminal on the same wall 3				
Y	Y From a boundary alongside the terminal 10				
Z	From a boundary facing the terminal	2000			

- If the outlet is installed less than 0.5 m horizontally and less than 2 m vertically from a public area, install an effective protector.
- Make sure that the mesh size of the guard does not effect the operation of the appliance.
- If the height of the outlet is less than 3 meter from the floor, the distance between the outlet and a garden or a terrace must be minimum 2 meter.

<sup>&</sup>lt;sup>1</sup> An opening here means an element that is permanent open (example: an air vent) or that can open (example: a door or window). But, in addition, the distance between outlet and built-in elements (example: window, door) must be minimum 300 mm.

<sup>&</sup>lt;sup>2</sup> Balcony or gallery of an apartment building.

4.4


#### Requirements on the concentric flue system



- Caution:
- Make sure that no flammable materials are located close to the flue system. The outer walls of the flue system can be 150 °C.
- Make sure that the part of the concentric flue system, which goes up from the ceiling, is in a casing.
  - Make sure that the casing is made of heat resistant material.
  - Make sure that air can flow in the casing. Use grates near the floor and near the ceiling. Do this for every floor where the casing is located.
- Do not insulate the concentric flue.

The parts that are required for the installation of the concentric flue system are numbered in the illustrations and refer to the part list in 6.

Use the universal wall/floor support (number 36 in the part list) to attach the concentric flue system to the casing and/or the floor.



Install a concentric flue system as described in this section.


Some configurations of the concentric flue system require the installation of a flue restriction plate. Different sizes of the flue restriction plate are delivered with the appliance. Refer to the Installation and maintenance manual.

#### 4.4.1 Possibilities for a concentric flue system with a roof outlet

# Rigid concentric flue systems

	Y	Flue gas restriction plate width
	(min max.)	Concentric connection on the appliance is Ø100-Ø150 mm
	2.0 - 4.0 m	30 mm
	4.0 - 12.0 m	40 mm

#### Box Gas 45




Y <sub>1</sub>	Х	$Y_{1} + Y_{2}$	Flue gas restriction plate width
(min max.)	(min max.)	(min max.)	Concentric connection on the appliance is Ø100-Ø150 mm
1.0 - 11.0 m	0 - 3.0 m	1.0 - 11.0 m	-



#### Caution:


Make sure that  $Y_1 + Y_2$  is at least 2 times larger than X.

#### Flexible concentric flue systems



Y	Flue gas restriction plate width
(min max.)	Concentric connection on the appliance is Ø100-Ø150 mm
2.0 - 4.0 m	30 mm
4.0 - 12.0 m	40 mm

Roof outlet using an flexible Ø100 mm liner in an existing lined chimney.




Y <sub>1</sub>	Х	$Y_1 + Y_2 + Y_3$	Flue gas restriction plate width
(min max.)	(min max.)	(min max.)	Concentric connection on the appliance is Ø100-Ø150 mm
1.0 - 11.0 m	0 - 3.0 m	1.0 - 11.0 m	-



#### Caution:

Make sure that  $Y_1 + Y_2 + Y_3$  is at least 2 times larger than X.


Roof outlet using an flexible Ø100 mm liner in an existing lined chimney.



	Y	Flue gas restriction plate width
	(min max.)	Concentric connection on the appliance is Ø100-Ø150 mm
	2.0 - 4.0 m	30 mm
	4.0 - 12.0 m	40 mm

Roof outlet using an flexible Ø100 mm liner and flexible Ø150 mm liner in an existing unsound lined chimney.

# bellfires <sup>gas fires</sup>



Y <sub>1</sub>	Х	$Y_1 + Y_2 + Y_3$	Flue gas restriction plate width
(min max.)	(min max.)	(min max.)	Concentric connection on the appliance is Ø100-Ø150 mm
1.0 - 11.0 m	0 - 3.0 m	1.0 - 11.0 m	-



Caution:

Make sure that  $Y_1 + Y_2 + Y_3$  is at least 2 times larger than X.


Roof outlet using an flexible Ø100 mm liner and flexible Ø150 mm liner in an existing unsound lined chimney.

#### 4.4.2 Possibilities for a concentric flue system with a wall outlet

Install the wall outlet in the correct position as shown in the figure. The centre of the inner pipe must be positioned above the centre of the outer pipe.




#### Rigid concentric flue systems




		Y	x	Flue gas restriction plate width
		(min max.)	(min max.)	Concentric connection on the appliance is Ø100- Ø150 mm
ĺ		1.0 - 2.0 m	0 - 7.0 m	-

# 5 Technical specification

# 5.1 Dimensions Box Gas 45







# 5.3 Dimensions of the restriction plate

Width of the delivered flue restriction plates in mm
Concentric flue connection Ø100 - Ø150
Roof-mounted outlet
30
40
50
65

# 6

# Available components for the concentric flue system



#### Caution:

Observe the installation instructions that are supplied with the components of the concentric flue system.

The gas fire, in combination with the concentric flue system [ $\emptyset$ 100 mm -  $\emptyset$ 150 mm] (rigid and/or flexible) for the brand types mentioned below, has been approved accordance with the European CE-norm for gas appliances and may therefore beused only with these systems.

#### Table 1: Approved brands

Manufacturer	system
Bellfires	Muelink & Grol system
Poujoulat	DUOGAS system
Ontop	Metaloterm US system
Jeremias/STB (STB = Schoorsteen Techniek- Brummen NL)	H-Twin system
Jeremias	TWIN-GAS system
Modinox	PLA system

The permitted components for these systems are listed in this chapter. The guarantee on the appliance lapses if it is installed, fully or partially,with other components or a different flue system. The concentric flue [ $\emptyset$ 100 mm -  $\emptyset$ 150 mm] systems can be used with either a newly-built or existing chimney.

Make sure that the wall or roof termination kit that is used for the installation of the concentric flue system is also listed in the available parts list.

#### 6.1 Appliance part list

Fig No.	Description
1	Gas fire; Concentric flue connection Ø100/Ø150 mm.
2	-
3	-
4	Restriction plate (The different sizes restriction plates are supplied with every appliance).
5	Chimney, min. Ø150 mm internal, totally gas tight.
6	Chimney or fireproof sleeving. min. Ø160 mm internal.
7	Ø100 mm internal flexible stainless steel gas vent chimney liner AISI 316TI.
8	Ø150 mm internal flexible stainless steel gas vent chimney liner AISI 316TI.
9	-

6.2	Bellfires - Muelink & Grol system Ø100 - Ø150
-----	---

Fig.	Bellfires			Color	(*)	Applic	cation
No.	Art./ Order No.	Description		stainless steel	antr.	rigid	flex
	302289	Twin-wall balanced flue pipe. L= 500 mm.		•		•	
10	346236	Twin-wall balanced flue pipe. L= 500 mm. BLACK			•	•	
	302290	Twin-wall balanced flue pipe. L= 1000 mm.		•		•	
11	346234	Twin-wall balanced flue pipe. L= 1000 mm. BLACK			•	•	
	302291	Telescopic twin-wall balanced flue pipe, L= min. 325 / max. 440 mm.		•		•	
12	346511	Telescopic twin-wall balanced flue pipe, L= min. 965 / max. 1750 mm.		•		•	
	302292	Adjustable length twin- wall balanced flue pipe, L= 500 mm.		•		•	
13	346237	Adjustable length twin- wall balanced flue pipe, L= 500 mm. BLACK			•	•	
	302299	Twin-wall balanced flue elbow 90°. (smooth)		•		•	
14	346238	Twin-wall balanced flue elbow 90°. (smooth), black			•	•	

Fig.	Bellfires		Color	(*)	Applicatio	
No.	Art./ Order No.	Description	stainless steel	antr.	rigid	flex
14	302297	Twin-wall balanced flue elbow 90°. (ribbed)	•		•	
14	346239	Twin-wall balanced flue elbow 90°. (segment) BLACK		•	•	
	302298	Twin-wall balanced flue elbow 45°. (ribbed)	•		•	
15	346240	Twin-wall balanced flue elbow 45°. (segment) BLACK		•	•	
	329514	Twin-wall balanced flue elbow 30°. (ribbed)	•		•	
	346507	Twin-wall balanced flue elbow 15°. (segment)	•		•	

Fig.	Bellfires			Color	(*)	Applic	cation
No.	Art./ Order No.	Description		stainless steel	antr.	rigid	flex
16	302295	Vertical (roof) termina- tion kit, L= 1360 mm. ANTHRACITE		•	•	•	•
17	302212	Adjustable roof flash- ing. Roof pitch 20° - 45° (**),with lead flashing.		٠		•	•
18	302213	Roof flashing for exist- ing chimney or flat roof.		•		•	•
	302296	Horizontal (wall) termi- nation kit, L= 600 mm (adjustable), including a set of wall spacer plates. ANTHRACITE		•	•	•	•
19	346241	Horizontal (wall) termi- nation kit, L= 600 mm (adjustable), including a set of wall spacer plates. Stainless steel. BLACK			•	•	•
	343949	Horizontal (wall) termi- nation kit, L= 600 mm (adjustable), including a set of wall spacer plates. Stainless steel.		•		•	•
20	302293	Stainless steel locking band Ø150 mm, quick- fastening.		•		•	•
21	302210	Silicone seal Ø150 mm.				•	•

Fig.	Bellfires			Color	(*)	Applie	cation
No.	Art./ Order No.	Description		stainless steel	antr.	rigid	flex
23	302215	Wall strap.	Ô	•		•	•
24	302214	Set of ceiling finishing plates / Fire stops.	0	•		•	•
25	302189	Ceiling plate for transi- tion Ø100 mm / Ø150 mm rigid -Ø100 mm flex.).		•		•	•
26	302278	Stainless steel adapt- er piece (100) from appliance to flexible, Ø100 mm external (rig- id) x Ø107 mm inter- nal (flex.). [appliance - Ø100 mm flex.] and [Ø100 mm rigid - Ø100 mm flex.].		•			•
27	302279	Stainless steel adapter piece (150) fire to flexi- ble, Ø148 mm external (rigid) x Ø148 mm in- ternal (flex.)[appliance - Ø150 mm flex.].		•			•
28	302217	Stainless steel locking band Ø150 mm. For adapter 150 [appliance - Ø150 mm (flex.)], Screw-fastening.		•		•	•
29	303776	Stainless steel screws Ø3.5 mm x 9.5 mm. For securing the flexible concentric flue. (Mini- mum 3 screws per con- nection).		•			•
30	304041	Hose clamp Ø100 mm. (Minimum 2 per con- nection).	$\bigcirc$	•			•

Fig.	Bellfires		Color	(*)	Applic	cation
No.	Art./ Order No.	Description	stainless steel	antr.	rigid	flex
31	304042	Hose clamp Ø150 mm. (Minimum 2 per con- nection)	•			•
32	302307	Vertical (roof) termina- tion kit, L = 610 mm. Suitable for a flexible flue system. ANTHRA- CITE	•	•	•	•
33	302301	Concentric T-piece with gauging orifice.	•		•	
34	302302	Concentric pipe with gauging orifice, L = 165 mm.	•		•	
35	302303	90° concentric bend with inspection panel.	•		•	
36	321948	Universal wall / floor support Ø150 mm	•		•	

#### (\*)Color

- Stainless steel, polished
- antr. : Anthracite or Black color lacquer, matt

(\*\*) Adjustable roof flashing for a slope > 45° can be supplied on request.

When installing a balanced-flue "closed" gas appliance in an existing chimney, ensure stainless steel flexible liners ( $\emptyset$ 100 mm or  $\emptyset$ 130 mm) conforming with EN 1856-2 are used to extract the flue gasses. The temperature classification of the flexible pipe must be at least T450.

# 6.3 Poujoulat - DUOGAS system Ø100 - Ø150

Fig No.	Poujoulat Art./ Order No.	Description	
	34100403	Twin-wall balanced flue pipe, L= 250 mm.	
10	34100404	Twin-wall balanced flue pipe. L= 450 mm.	
11	34100405	Twin-wall balanced flue pipe. L= 950 mm.	
12	34100429	Telescopic twin-wall balanced flue pipe, L= min. 390 / max. 640 mm.	
14	34100441	Twin-wall balanced flue elbow 90°.	
15	34100421	Twin-wall balanced flue elbow 45°.	
15	34100411	Twin-wall balanced flue elbow 30°.	
15	34100401	Twin-wall balanced flue elbow 15°.	

Fig No.	Poujoulat Art./ Order No.	Description	
16	34100654	Vertical (roof) termination kit, L= 140 mm .	
17	45150171	Roof flashing, suitable for a brick roof, with a roof pitch of 15°- 30°.	
17	45150170	Roof flashing, suitable for a tiled roof, with a roof pitch of 15°- 30°.	
17	45150172	Roof flashing, suitable for a brick roof, with a roof pitch of 30°- 45°.	
17	45150173	Roof flashing, suitable for a tiled roof, with a roof pitch of 30°- 45°.	
18	45150169	Roof flashing for existing chimney or flat roof.	
19	34100610	Horizontal (wall) termination kit, L= min. 365 mm / max. 585 mm.	
20	45150076	Stainless steel locking band Ø150 mm, quick-fastening.	
23	45150072	Wall strap, Ø150 mm.	

Fig No.	Poujoulat Art./ Order No.	Description	
24	37100442	Ceiling/wall plate with spacers and ventilation grooves.	
24	37100425	Set of ceiling finishing plates / Fire stops,suitable for a roof pitch of 0°- 10°.	
24	37100426	Set of ceiling finishing plates / Fire stops,suitable for a roof pitch of 10°- 30°.	
24	37100427	Set of ceiling finishing plates / Fire stops,suitable for a roof pitch of 30°- 40°.	
24	37100428	Set of ceiling finishing plates / Fire stops,suitable for a roof pitch of 40°- 50°.	
34	34100407	Concentric pipe with inspection opening, L= 250 mm.	
36	45150165	Roof support, (universal) Ø150 mm.	
36	45150081	Floor support, (universal) Ø150 mm.	
37	34100611	Adapter: Bellfires Ø100-150 mm $\rightarrow$ Poujoulat DUOGAS Ø100-150 mm(Appliance 100/150 $\rightarrow$ Poujoulat DUO- GAS 100/150)	
100	34100614	Adapter: Bellfires Ø130-200 mm → Poujoulat DUOGAS Ø100-150 mm(Appliance 130/200 → Poujoulat DUO- GAS 100/150)	
101	34100613	Concentric reduction of Poujoulat DUOGAS Ø130-200 mm → Poujoulat DUOGAS Ø100-150 mm	

# 6.4 Ontop - Metaloterm US system Ø100 - Ø150

Fig. No.	Ontop Art. / Order No.	Description	
	USA 10	Adapter for Bellfires appliances with Ø100-Ø150 mm concentric connection.	
	US 25 10	Twin-wall balanced flue pipe, L = 250 mm.	
10	US 50 10	Twin-wall balanced flue pipe. L= 500 mm.	
11	US 100 10	Twin-wall balanced flue pipe. L= 1000 mm.	
12	USPP 10	Telescopic twin-wall balanced flue pipe, L= min. 60 / max. 250 mm.	
14	USB 90 10	Twin-wall balanced flue elbow 90°.	
15	USB 45 10	Twin-wall balanced flue elbow 45°.	
15	USB 30 10	Twin-wall balanced flue elbow 30°.	

Fig. No.	Ontop Art. / Order No.	Description	
15	USB 15 10	Twin-wall balanced flue elbow 15°.	
16	USDVC2 10	Vertical (roof) termination kit, L= 375 mm.	
16	USSR 10	Storm collar Ø150 mm.	
17	USLS 10	Adjustable roof flashing. Roof pitch 20° - 45°, with lead flashing.	$\square$
17	USDH 10	Roof flashing plate for roof pitch 5°- 30°.	
18	USDP 10	Roof flashing for existing chimney or flat roof.	
18	USDPAL 10	Roof flashing - Aluminum - For existing chimney or flat roof.	
19	USDHC5 10	Horizontal (wall) termination kit, L= 475 mm (adjusta- ble).	
20	USKB 10	Locking band, quick-fastening.	

Fig. No.	Ontop Art. / Order No.	Description	
21	USAB 10	Cover band, screw-fastening.	
23	USMB 10	Wall strap, adjustable.	
23	USEB 10	Fitting bracket.	
24	USCP 10	Set of ceiling finishing plates / Fire stops /Centering plates.	
24	USDQ 10	Roof support.	THE
25	USSAN 10	Renovation set.	
25	USSAN1 10	Top of renovation set.	
25	USSAN2 10	Bottom renovation set.	

Fig. No.	Ontop Art. / Order No.	Description	
28	USKBS 10	Locking band, screw-fastening.	
	USI 10	Concentric pipe with inspection panel,L= 250 mm.	
34	USEM 10	Concentric pipe with gauging orifice,L= 150 mm.	
35	USBI 10	90° concentric bend with inspection panel.	
	USR 10	Rosette smooth Ø150 mm.	, ,
	USMPG 10	Wall plate large Ø150 mm, square 300 mm.	
	USAH 10	Spacer bracket.	
	USVG 10 13	Concentric reduction of Ø100-Ø150 mm → Ø130-Ø200 mm.	

# 6.5 Jeremias/STB - H-Twin system Ø100 - Ø150

Fig. No.	Jeremias Art. / Order No.	Description	
11	ATWINL 13100-150	Twin-wall balanced flue pipe. L= 1000 mm.	
10	ATWINL 14100-150	Twin-wall balanced flue pipe. L= 500 mm.	
10	ATWINL 15100-150	Twin-wall balanced flue pipe. L= 250 mm.	
12	H-TWIN 742100-150	Telescopic twin-wall balanced flue pipe, L= min. 1100 / max. 1400 mm.	
12	H-TWIN 467100-150	Telescopic twin-wall balanced flue pipe, L= min. 1100 / max. 1900 mm.	
12	ATWIN 197100-150	Telescopic twin-wall balanced flue pipe, L= min. 600 / max. 900 mm.	
15	ATWIN 16 100-150	Twin-wall balanced flue elbow 15°.	

Fig. No.	Jeremias Art. / Order No.	Description	
15	ATWIN 17 100-150	Twin-wall balanced flue elbow 30°.	
15	ATWIN 18 100-150	Twin-wall balanced flue elbow 45°.	
14	ATWIN 60100-150	Twin-wall balanced flue elbow 90°.	
14	ATWIN 60F100-150	Twin-wall balanced flue elbow 90° - Short.Especially for connection to a wall termination.	
16	A 463100-150	Roof termination - long, with pipe,L = 1080 mm, Verti- cal.	

Fig. No.	Jeremias Art. / Order No.	Description	
16	ATWIN 92100-150	Roof termination - short with pipe,L = 300 mm, Vertical.	
32	ATWIN 92pe100-15 0	Roof termination, with pipe,L = 495 mm, Vertical, with roof flashing for existing chimney or flat roof.	
17	ATWIN 45DD 100-150	Roof flashing for roof pitch 30°,with lead flashing and storm collar.	
17	ATWIN 60DD 100-150	Roof flashing for roof pitch 45°,with lead flashing and storm collar.	
	ATWIN 307 100-150	Storm collar.	
24	ADBL- DW100-150	Set of ceiling finishing plates / Fire stops.	C
20	ATWIN 45100-150	Locking band, Screw-fastening (Standard on all components).	
23	ATWIN 22100-150	Wall strap, adjustable.	
23	ATWIN 23100-150	Wall strap, distance adjustable 60-250 mm.	

Fig. No.	Jeremias Art. / Order No.	Description	
19	A681100-15 0	Horizontal (wall) termination kit, L= 495 mm (horizontal- ly adjustable), including one set of wall spacer plates.	
33	H-TWIN 752100-150	Concentric T-piece with gauging orifice. Inspection panel with cover cap and condensation-opening.	
	ATWIN 465 100-150	Adapter: H-TWIN Ø100-150 → Flex Stainless steel ; Ø100 mm Incl. Ceiling plate 300x300 mm.	
	ATWIN 466100-150	Adapter: Flex Stainless steel; Ø100 mm → H-TWIN Ø100-150 Incl. Chimney(ceiling)plate 300x300 mm.	
36	ASDH2 100-150	Universal wall / floor supportØ150 mm.	A Lesenstiering auth gegenbler
100	A464 130	Concentric reduction of H-TWIN Ø130 / Ø200 mm → H-TWIN Ø100 / Ø150 mm.	

## 6.6 Jeremias - TWIN-GAS system Ø100 - Ø150

Fig. No.	Jeremias Art. / Order No.	Description	
	TWG163410 0-150	Bellfires Appliance connection / AdapterBellfires Ø100/150 mm → Jeremias TWIN-GAS Ø100/150 mmL = 160 mmIncluding locking band (2x).	
11	TWG13100- 150	Twin-wall balanced flue pipe, L = 1000 mmIncluding locking band.	
10	TWG14100- 150	Twin-wall balanced flue pipe, L = 500 mmIncluding locking band.	
10	TWG15100- 150	Twin-wall balanced flue pipe, L = 250 mmIncluding locking band.	
	TWG180110 0-150	Twin-wall balanced flue pipe, L = 1000 mmwith 4 spacer brackets on the outsideIncluding locking band.	

Fig. No.	Jeremias Art. / Order No.	Description	
12	TWG50100- 150	Telescopic twin-wall balanced flue pipe,L= min. 330 / max. 420 mmIncluding locking band.	
15	TWG16100- 150	Twin-wall balanced flue elbow 15°. Including locking band.	
15	TWG17100- 150	Twin-wall balanced flue elbow 30°. Including locking band.	
15	TWG18100- 150	Twin-wall balanced flue elbow 45°. Including locking band.	
14	TWG60100- 150	Twin-wall balanced flue elbow 90°. Including locking band.	
14	TWG178610 0-150	Twin-wall balanced flue elbow 90° - with support leg Including locking band and sealing cap under.	
14	TWG167610 0-150	Twin-wall balanced flue elbow 90° - short - eccen- tric.Especially for connection to a wall termination TWG1619Including locking band.	

Fig. No.	Jeremias Art. / Order No.	Description	
16	TWG272100 -150	Roof termination (vertical) L= 615 mm.Including locking band.	
17	TW53150	Roof flashing with a roof pitch of 5° - 15°with flex. alu- flashing and storm collar.	
17	TW59 150	Roof flashing with a roof pitch of 16° - 25° with flex. alu-flashing and storm collar.	
17	TW38 150	Roof flashing with a roof pitch of 26° - 35°with flex. alu-flashing and storm collar.	
17	TW54 150	Roof flashing with a roof pitch of 36° - 45°with flex. alu-flashing and storm collar.	
18	TW52150	Roof flashing for existing chimney or flat roofwith storm collar.	
	KL72150	Storm collar(spare part).	
19	TWG161910 0-150	Wall termination kit, L= 600 mm (horizontal)Adjustable. Incl. locking band and one set of wall spacer plates.	00

Fig. No.	Jeremias Art. / Order No.	Description	
20	TW45150	Locking band, screw-fastening(spare part).	
21	ALBI26150	Silicone sealing ring for outer pipe(spare part).	0
23	ZU- WA704150	Wall strap. Distance to the wall: WA= 50 mm.	
	ZU- WA891130	Extension pieces for the wall strap ZUWA704L= 130 mm.	36.35
	ZU- WA891200	Extension pieces for the wall strap ZUWA704L= 200 mm.	35 - 35
	ZU- WA891250	Extension pieces for the wall strap ZUWA704L= 250 mm.	35
	ZUWA706	Extension pieces for the wall strap ZUWA704L= 400 mm, WA = 50 - 360 mm.	
24	ZU- DA074150	Set of ceiling finishing plates / Fire stopsfor a flat roof : $0^{\circ}$ .	
24	ZU- DA99V150	Set of ceiling finishing plates / Fire stopsfor a pitched roof : 0° - 30°.	
24	ZU- DA98V150	Set of ceiling finishing plates / Fire stopsfor a pitched roof : 31° - 45°.	

Fig. No.	Jeremias Art. / Order No.	Description	
24	ZU- DA99VHL15 0	Set of ceiling finishing plates / Fire stops with ventila- tion openings for a pitched roof : 0° - 30°.	
24	ZU- DA98VHL15 0	Set of ceiling finishing plates / Fire stopswith ventilation openings for a pitched roof : 31° - 45°.	
25	FD08 100	Adapter: TWIN-GAS to FLEX. (only for the inner pipe Ø100 mm).	
25	TWG1276D 100-150	Chimney-/flat roof-/ceiling - platewith adapter: FLEX to TWIN-GAS.	
25	ZU- WA1618100	Adapter: TWIN-GAS to 'Schaft' (DE).	
25	TWG173210 0-150	Chimney-/flat roof-/ceiling - platewith adapter: Ø100 rig- id/flex. to TWIN-GAS .	
33	TWG317100 -150	Concentric T-piece 90°.Including locking band.	
34	TWG51100- 150	Concentric pipe with gauging orificeL= 200 mm. Includ- ing locking band.	
35	TWG10 100-150	Concentric pipe, L= 300 mmwith cleaning opening/in- spection panel.Including locking band.	12 M
35	TWG19100- 150	Concentric elbow 90° with cleaning opening/inspection panel.Including locking band.	
36	TWG05100- 150	Base plate/Cover-under with 2x ½" gauging orifice, sealing cap and condensate drain at the bottom.	

Fig. No.	Jeremias Art. / Order No.	Description	
36	TWG07100- 150	Base plate / floor support.	
	DW391	Wall support with transverse supportType I: 350 mm - Distance to wall: WA= max. 50 mm.	
	DW392	Wall support with transverse supportType II: 500 mm - Distance to wall: WA= 50 - 150 mm.	
	DW393	Wall support with transverse supportType III: 750 mm - Distance to wall: WA= 150 - 250 mm.	
	DW407	Wall support with transverse supportType IV: 1030 mm - Distance to wall: WA= 250 - 360 mm.	
(17-24)	LUX- ECO150	Insulation roof flashing, L= Max. 500 mm (adjustable). Wall thickness LUX-ECO Insulation: min. 25 mm.	
(19)	LUX- ECO150	Insulation wall flashing, L= Max. 360 mm(adjustable). Wall thickness LUX-ECO Insulation: min. 25 mm.	

## 6.7 Modinox - PLA system Ø100 - Ø153

Ci.e.				Color (*)		Application	
Fig. No.	Modinox Art./ Order No.	Description		stainles steel	antr.	rigid	flex
	2PLAMAFM100BEL	Bellfires appli- ance connec- tion: Adapter Bellfires Ø100/150 mm → Modinox PLA Ø100/153 mm. L= 230 mm. INOX		•		•	
	2PLAMAFM100BELNO	Bellfires appli- ance connec- tion: Adapter Bellfires Ø100/150 mm → Modinox PLA Ø100/153 mm. L= 230 mm. INOX - BLACK			•	•	
	2PLAELDR100250	50 Twin-wall bal- anced flue pipe, L= 250 mm., INOX		•		•	
10	2PLAELDR100250NO	Twin-wall bal- anced flue pipe, L= 250 mm., INOX - BLACK			•	•	
	2PLAELDR100330	Twin-wall bal- anced flue pipe, L= 330 mm., INOX		•		•	
10	2PLAELDR100330NO	Twin-wall bal- anced flue pipe, L= 330 mm., INOX - BLACK			•	•	
	2PLAELDR100500	Twin-wall bal- anced flue pipe, L= 500 mm., INOX		•		•	
10	2PLAELDR100500NO	Twin-wall bal- anced flue pipe, L= 500 mm., INOX - BLACK			•	•	

Fig.				Color (*)		Application	
No.	Modinox Art./ Order No.	Description		stainles steel	antr.	rigid	flex
	2PLAELDR1001000	Twin-wall bal- anced flue pipe, L= 1000 mm., INOX		•		•	
11	2PLAELDR1001000NO	Twin-wall bal- anced flue pipe, L= 1000 mm., INOX - BLACK			•	•	
12	2PLAELRE100500	Telescopic twin-wall bal- anced flue pipe, L= min. 300 / max. 500 mm., IN- OX		•		•	
	2PLAELRE100500NO	Telescopic twin-wall bal- anced flue pipe, L= min. 300 / max. 500 mm., IN- OX - BLACK			•	•	
	2PLACO90100	Twin-wall bal- anced flue el- bow 90°, IN- OX		•		•	
14	2PLACO90100NO	Twin-wall bal- anced flue el- bow 90°, IN- OX - BLACK	H		•	•	
15	2PLACO45100	Twin-wall bal- anced flue el- bow 45°, IN- OX		•		•	
13	2PLACO45100NO	Twin-wall bal- anced flue el- bow 45°, IN- OX - BLACK			•	•	
15	2PLACO30100	Twin-wall bal- anced flue el- bow 30°, IN- OX		•		•	
	2PLACO30100NO	Twin-wall bal- anced flue el- bow 30°, IN- OX - BLACK			•	•	

Fig.		Description		Color (*)		Application	
No.	Modinox Art./ Order No.			stainles steel	antr.	rigid	flex
15	2PLACO15100	Twin-wall bal- anced flue el- bow 15°, IN- OX		•		•	
	2PLACO15100NO	Twin-wall bal- anced flue el- bow 15°, IN- OX - BLACK			•	•	
	2PLACHAR100	Vertical (roof) termination cap, L= 360 mm, INOX		•		•	
16	2PLACHAR100NO	Vertical (roof) termination cap, L= 360 mm, INOX - BLACK			•	•	
17	2DIVS5IN150	Roof flashing for a roof pitch of 5°- 30°, IN- OX		•		•	
	2DIVS5IN150NO	Roof flashing for a roof pitch of 5°- 30°, IN- OX - BLACK			•	•	
	2DIVS3IN150	Roof flashing for a roof pitch of 31°- 45°, INOX		•		•	
17	2DIVS3IN150NO	Roof flashing for a roof pitch of 31°- 45°, INOX - BLACK			•	•	
17	2DIVRTS1	Roof tile fitting for roof flash- ing			•	•	
	2DIVCSOL153	Collar for roof flashing, IN- OX		•		•	
17	2DIVCSOL153NO	Collar for roof flashing, IN- OX - BLACK		•		•	
	2DIVJOCO155	Sealing ring for collar roof flashing				•	

Fig. Modinov Art ( Order No.				Color (*)		Application	
No.	Modinox Art./ Order No.	Description		stainles steel	antr.	rigid	flex
	2DIVS5PS160	Roof flashing, standard model, lead: 0,6mm thick, for a roof pitch of 5°- 30°, with INOX cone		•		•	
17	2DIVS5PR160	Roof flashing, large tile mod- el, lead: 1,0mm thick, for a roof pitch of 5°- 30°, with INOX cone		•		•	
	2DIVS3PS160	Roof flashing, standard model, lead: 0,6mm thick, for a roof pitch of 31°- 45°, with INOX cone		•		•	
	2DIVS3PR160	Roof flashing, large tile mod- el, lead: 1,0mm thick, for a roof pitch of 31°- 45°, with INOX cone		•		•	
17	2DIVC5LA153NO	Cone cover for roof flash- ing, lead, for a roof pitch of 5°- 30°, INOX - BLACK			•	•	
	2DIVC3LA153NO	Cone cover for roof flash- ing, lead, for a roof pitch of 31°- 45°, IN- OX - BLACK			•	•	
	2DIVSOIN150	Roof flashing for existing chimney or flat roof, INOX		•		•	
18	2DIVSOIN150NO	Roof flashing for existing chimney or flat roof, INOX - BLACK			•	•	

Fig.				Color (*)		Application	
No.	Modinox Art./ Order No.	Description		stainles steel	antr.	rigid	flex
	2PLATHOR100	Horizontal (wall) termina- tion kit, with rosettes, L= min. 580 mm / max. 780 mm. INOX		•		•	
19	2PLATHOR100NO	Horizontal (wall) termina- tion kit, with rosettes, L= min. 580 mm / max. 780 mm. INOX - BLACK			•	•	
	2PLACOJO100	Locking band, quick-fasten- ing. INOX		•		•	
20	2PLACOJO100NO	Locking band, quick-fasten- ing. INOX - BLACK			•	•	
21	2PLAJOIF100	Fiber seal	$\bigcirc$			•	
	2PLACOMU100	Wall strap, IN- OX		•		•	
23	2PLACOMU100NO	Wall strap, IN- OX - BLACK			•	•	
23	2PLASUPLR100	Wall support, quick fasten- ing		•		•	
24	2PLACOCF100	Set of ceiling finishing plates / Fire stops		•		•	
24	2PLAPVEN100	Ceiling finish- ing plate with ventilation openings		•		•	

Fig.	Modinox Art./ Order No.	Description		Color (*)		Application	
No.				stainles steel	antr.	rigid	flex
	2PLAROSA100BT	Rosette, IN- OX		•		•	
24	2PLAROSA100BTNO	Rosette, IN- OX - BLACK			•	•	
	2PLAROSA100BTBL	Rosette, IN- OX - WHITE				•	
	2PLAROSA100	Rosette with 4 mounting holes, INOX		•		•	
24	2PLAROSA100NO	Rosette with 4 mounting holes, INOX - BLACK			•	•	
	2PLAROSA100BL	Rosette with 4 mounting holes, INOX - WHITE				•	
	2PLAEMES100	Concentric pipe with gauging ori- fice, L= 250 mm, INOX		•		•	
34	2PLAEMES100NO	Concentric pipe with gauging ori- fice, L= 250 mm, INOX - BLACK			•	•	
35	2PLAERAM100	Concentric pipe with in- spection/ cleaning opening, L= 260 mm.		•		•	
36	2PLACOSO100	Floor support strap		•		•	
36	2PLACTOS100	Roof strap		•		•	

Fig.				Color	(*)	Applic	cation
No.	Modinox Art./ Order No.	Description		stainles steel	antr.	rigid	flex
36	2PLAEPDS100	Clearance roof/floor pas- sage		•		•	
25	2PLAADA71002020	Adapter Modi- nox PLA → Flexible pipe, with chimney bottom finish- ing plate 200x200mm, INOX		•		•	•
	2PLAADA71002020NO	Adapter Modi- nox PLA → Flexible pipe, with chimney bottom finish- ing plate 200x200mm, INOX - BLACK			•	•	•
25	2PLAADA71002525	Adapter Modi- nox PLA → Flexible pipe, with chimney bottom finish- ing plate 250x250mm, INOX		•		•	•
	2PLAADA71002525NO	Adapter Modi- nox PLA → Flexible pipe, with chimney bottom finish- ing plate 250x250mm, INOX - BLACK			•	•	•

Fig.	Modinox Art./ Order No.	Description		Color (*)		Application	
No.				stainles steel	antr.	rigid	flex
25	2PLAADA71003030	Adapter Modi- nox PLA → Flexible pipe, with chimney bottom finish- ing plate 300x300mm, INOX		•		•	•
	2PLAADA71003030NO	Adapter Modi- nox PLA → Flexible pipe, with chimney bottom finish- ing plate 300x300mm, INOX - BLACK			•	•	•
25	2PLAADA71002040	Adapter Modi- nox PLA → Flexible pipe, with chimney bottom finish- ing plate 200x400mm, INOX		•		•	•
	2PLAADA71002040NO	Adapter Modi- nox PLA → Flexible pipe, with chimney bottom finish- ing plate 200x400mm, INOX - BLACK			•	•	•
25	2PLAADA71003040	Adapter Modi- nox PLA → Flexible pipe, with chimney bottom finish- ing plate 300x400mm, INOX		•		•	•
	2PLAADA71003040NO	Adapter Modi- nox PLA → Flexible pipe, with chimney bottom finish- ing plate 300x400mm, INOX - BLACK			•	•	•

Fig.				Color (*)		Application	
No.	Modinox Art./ Order No.	Description		stainles steel	antr.	rigid	flex
	2PLAADA61002020	Adapter Flexi- ble pipe → Modinox PLA, with chimney top finishing plate 200x200mm, INOX		•		•	•
	2PLAADA61002525	Adapter Flexi- ble pipe → Modinox PLA, with chimney top finishing plate 250x250mm, INOX		•		•	•
25	2PLAADA61003030	Adapter Flexi- ble pipe → Modinox PLA, with chimney top finishing plate 300x300mm, INOX		•		•	•
	2PLAADA61002040	Adapter Flexi- ble pipe → Modinox PLA, with chimney top finishing plate 200x400mm, INOX		•		•	•
	2PLAADA61003040	Adapter Flexi- ble pipe → Modinox PLA, with chimney top finishing plate 300x400mm, INOX		•		•	•
	2PTGKIMU100	Insulation kit ISOMU for wall passage		•		•	

Fig.	Modinox Art./ Order No.	Description		Color (*)		Application	
No.				stainles steel	antr.	rigid	flex
	2PTGKIRA100 + la pente	Insulation kit ISORA for pitched roof passage		•		•	
	2PTGKIRAV100 + la pente	Insulation kit ISORA for pitched roof passage, roof and floor, in- cludes a junc- tion collar and 4 ventilation grilles		•		•	
	2PTGKIFO100	Insulation kit FOURP for ceiling pas- sage. Com- plete wood floor kit		•		•	
	2PTGKIFO100BE	Insulation kit FOURP for ceiling pas- sage. Com- plete concrete floor kit		•		•	
	2PTGKIFOV100	Insulation kit FOURP for ceiling + stor- ey floor pas- sage. Com- plete wood floor kit		•		•	
	2PTGKIFOVBE100	Insulation kit FOURP for ceiling + stor- ey floor pas- sage. Com- plete concrete floor kit		•		•	
	2PTGPPDR100BL	Ceiling finish- ing plates - Whit lac- quered - Op- tion for kit FOURP	0	•		•	

## bellfires.

Your Bellfires dealer

30.01.2024 - 346076 - 28-003